





DE'LONGHI INT/A/RU/SKA/EST/TR ECAM26.455.M 0132215118

Pos.	Spare part code	Description
	5332224100	MOTOR BELT GRINDER
001	5513216231	REAR PANEL
002	7313220771	COVER
003	5313225831	COVER DUST
004	5513216841	COVER
006	5313225801	COVER
007	7313220781	CONTROL PANEL ASSEMBLY
009	7313220791	COVER ASSEMBLY
010	5332100800	TUBE
013	5313218761	CARAFE
014	5332169200	MEASURING SPOON
015	5313225791	COVER
016	5513216211	SIDE RIGHT
017	5513216221	SIDE LEFT
020	5313214981	FILTER
023	6113210251	SPRING
024	7313220761	TANK
025	5513216191	FRONT PANEL
026	5513216181	FRONT PIECE
027	7313220481	DISTRIBUTING
028	7013211031	CUP PLATE
029	5513216201	CONTAINER
030	5313213551	TRAY
032	7313220801	PIPETTE
033	5313222641	FLOAT
034	5313226961	TRAY
035	5332177500	O-RING
036	5313217751	O-RING

DE'LONGHI INT/A/RU/SKA/EST/TR ECAM26.455.M 0132215118

Pos.	Spare part code	Description
037	5332169300	TUBE LOWER
038	5532154000	FROTHER
039	5913212631	KNOB
040	5313225891	COVER
041	5513217201	LED
042	9812631250	SCREW
043	5313227651	COVER
044	7313218501	DIFFUSER KIT
045	5313213191	LEVER
046	6032105300	DIFFUSER
047	5332139500	VALVE
048	5332149100	O-RING
049	6113210131	SPRING
050	5332139600	STOPPER
053	6132112200	SPRING
054	5313213211	PISTON
055	5313213241	RUBBER PAD
056	5313213591	STOPPER
057	7313212631	TROLLEY
058	5313224561	INNER COVER
059	7313214521	REGULATOR
060	6113210161	PIN
061	9820000480	WASHER
062	9813431616	SCREW
064	7313220361	COMPLETE GRINDER
065	5113210211	SPRING MICROSWITCH
066	5313225951	SUPPORT
067	5113210371	SWITCH

DE'LONGHI INT/A/RU/SKA/EST/TR ECAM26.455.M 0132215118

Pos.	Spare part code	Description
068	5232114100	CONNECTOR
069	9813431616	SCREW
070	5313213371	FLAP
071	5113210051	PUMP
072	7332196700	HEATING Element ASSY
073	6113210201	SPRING
074	5313216281	SUPPORT
075	5313213391	ARM
076	6113210181	SPRING
077	5313213431	RUBBER PAD
079	5313229731	FOOT
080	5513217161	TUBE PTFE DI2-DE4 L=270 2BUSHES
081	9813433816	SCREW
082	5013211481	POWER SUPPLY CORD
083	5513216251	TUBE PTFE DI2-DE4 L=460 1BUSHE
084	5313217701	O-RING D=3,85
085	5513212871	TUBE PTFE DI2-DE4 L=97 2BUSHES
086	5213213711	TCO
087	5213211161	PROTECTOR
088	6132101300	SPRING
089	5513211371	REGULATOR
090	5313213251	SUPPORT
091	5332199500	TUBE DI=4 L=150
093	5213214061	SENSOR NTC
094	5213212861	WATER VOLUME METER
095	5313215271	TUBE
096	7313220251	TRANSMISSION KIT
098	5313217691	O-RING D=4,5

DE'LONGHI INT/A/RU/SKA/EST/TR ECAM26.455.M 0132215118

Pos.	Spare part code	Description
099	5213214081	SOLENOID VALVE 2V
101	5332170600	BELT
102	5213214051	SENSOR BOARD
103	5213211081	BOARD
104	5132110500	MICROSWITCH
105	5513213101	TUBE PTFE DI2-DE4 L=380 2BUSHES
106	5313227841	TUBE 90°
107	5513212901	TUBE PTFE DI2-DE4 L=290 2BUSHES
108	5332239200	CONNECTION
109	5313225171	CONNECTION
110	5313224491	SUPPORT
111	5213214021	SOLENOID VALVE 3V PLASTIC
112	5313225161	STOPPER
113	5513213761	TUBE PTFE DI2-DE4 L=190 2BUSHES
114	5513212881	TUBE PTFE DI2-DE4 L=270 2BUSHES
116	7313212561	VALVE
117	5313217871	TUBE DI=3 DE=6 L=200
118	5313213021	ARCHIMEDES SCREW
119	5113210211	SPRING MICROSWITCH
120	5513214291	GENERATOR
121	5313218351	CONNECTION
123	5013252961	WIRING TCO
124	5013252541	WIRING TCO
125	5332239300	SPACER
126	6113210021	SPRING
127	5513213901	TUBE PTFE DI2-DE4 L=320 2BUSHES
128	5213214071	SOLENOID VALVE CEME 5220VN2
129	5132104100	MICROSWITCH

DE'LONGHI INT/A/RU/SKA/EST/TR ECAM26.455.M 0132215118

Pos.	Spare part code	Description
130	5313218821	SUPPORT MICROSWITCH
133	7313224081	VALVE
135	5332149100	O-RING
136	5313217601	FILTER
137	9812631250	SCREW
138	5313220131	RUBBER PAD
139	7313220841	COUPLING
140	5313220031	O-RING
143	5313221011	O-RING
144	6132101300	SPRING
145	5132104100	MICROSWITCH
146	5232104600	SENSOR REED
147	6213210351	NUT
148	6232114700	BUSH
149	7013210391	CONNECTION
150	6113210741	CONNECTION
151	5213215201	POWER BOARD

Spare parts list extract from the site on 25-01-2012